

TECHNICAL DATA SHEET

VISTA

READY TO USE OVEN & GRILL CLEANER

Ready-to-use oven and grill cleaner removes baked-on grease from ovens, grills, stoves. Use on hoods, deep fat fryers, stainless steel counters, chrome utensils. Positive cleaning plus convenience.

DIRECTIONS

Wear Rubber Gloves and Apron with Sleeves

OVENS AND GRILLS

Preheat oven 200°F. Turn off. Apply cleaner. Allow to remain 5 to 10 minutes. Wipe off and rinse with water containing vinegar, then with clear water. For stubborn spots, repeat. If surface is cool, allow to work 15 minutes before wiping off. Use grill stone (brick) for stubborn spots or if oven, grill is cold.

DEEP FAT FRYERS

Fill fryer with water. Add 8 to 16 oz. of product per gallon of water. Heat solution. Let stand 5-10 minutes. Scrub sides of fryer with a long-handled pot brush. Dispose of soiled water and cleaner. Rinse well with water.

OTHER SURFACES

Stainless steel counters and chrome use 8 fl. oz. VISTA per gallon of water. Spray or wipe on surface. Allow to remain on surface a few minutes, then rinse.

Do not use on aluminum, linoleum, asphalt tile, copper, painted surfaces, fabrics. Protect these surfaces when cleaning.

ADVANTAGES

- Cleans ovens, grills, filters, hoods, stoves, deep fat fryers, stainless steel counters, and chrome utensils.
- Removes baked-on grease.
- VISTA is a degreaser and carbon remover made for use on cooking equipment, utensils, and other associated surfaces.

SPECIFICATIONS

Physical Form	Clear Liquid
Color	Amber
Scent	Surfactant
Specific Gravity	1.06
Density	8.84 lbs. per gallon
Foam Test 1% Solution	Initial - 70 mm 5 minutes - 57 mm
pH 2%	12.0
Active Alkalinity	3.716%
Total Alkalinity	3.988%
Total Solids	7.84%

DANGER: May be harmful if swallowed.
Causes severe skin burns and eye damage.
Causes serious eye damage.
Keep out of reach of children.

SHIPPING WEIGHT IN POUNDS:

Case 4 Plastic Gallons 38.07 pounds

**1ST
L^{AYD}**

